

Automated Boiler Blowdown

I. Blowdown Basics

- A. Boilers generate steam used for heating or manufacturing processes.
- B. When steam leaves the boiler, impurities (TDS total dissolved solids) are left behind to accumulate in the boiler.
- C. Accumulation of TDS beyond their solubility limit results in the formation of scale.
- D. Blowdown is the process of removing water with high concentrations of TDS and replacing it with fresh makeup water with lower levels of TDS, thereby lowering the overall TDS in the boiler.
- E. Two types of blowdown: Bottom blowdown removes sediment/sludge from the bottom of the boiler; Surface skimmer blowdown removes high-TDS water near the surface (6" below the water line). Automated controllers only regulate surface blowdown (illegal to automate bottom blowdown).
- F. TDS can be directly measured by lab tests (costly, time consuming) or can be approximated by conductivity measurements (inexpensive, quick, accurate).
- G. Two types of surface blowdown: manual and automated

II. Manual Blowdown

- A. Involves manually opening a blowdown valve at various times throughout the day; used in conjunction with a hand-held conductivity meter to keep some degree of control over TDS levels.
- B. Results in high and low conductivity spikes due to boiler load variances.
- C. Conductivity levels above the target maximum lead to the formation of scale. Conductivity levels below the target maximum result in excess water and chemical usage.
- D. At best, manual systems err on the safe side and keep TDS too low.
- E. Excess water usage has several costs:
 - 1. City water costs
 - 2. City sewer costs
 - 3. Energy costs (heated water is sent to drain)
 - 4. Chemical costs (tied to water usage)
- F. High TDS = Scale Formation = Energy Inefficiencies
 - 1. 1/16" layer of scale results in a 10% minimum reduction in heat transfer efficiency (a percentage reduction in heat transfer efficiency = a direct percentage increase in heating costs).
 - 2. Extreme scale build-up leads to costly de-scaling procedures or the replacement of boiler tubes or complete systems.

Automated Boiler Blowdown Cont.

III. Automated Blowdown

- A. Uses an automated controller and valves to continuously or intermittently sample the boiler water and then blowdown as needed.
- B. Types of Automated Blowdown
 - Continuous Sampling Used when steam blowdown requirements exceed 5000 lbs./hr. (see selection guide). A sample of water is continuously sent across the conductivity probe to drain. When conductivity levels exceed the target maximum, a larger blowdown valve opens and sends more water to drain until the set point is satisfied.
 - 2. Timed Sampling (most common) Used when steam blowdown requirements are less than 5000 lbs./hr. A sample of water is intermittently sent across the probe for a predetermined amount of time (interval and duration are adjustable), and the blowdown valve is held open until the conductivity set point is satisfied.

C. Cost Justification


- Auto blowdown allows for much tighter control of conductivity levels (typical 20% increase in conductivity levels vs. manual control; this equals a direct 20% savings in fuel)
- b. Less blowdown and makeup required = lower water and sewage bills
- c. Less water usage = lower chemical costs
- d. Less testing and manual care required (time freed up for more productive work)
- e. Prevention of scale formation protection of capital equipment costs f.Average payback for a typical system is a couple of months (see "Cost Justification" sheet).

IV. Typical Installation (See timed-sampling drawing)

- A. Required components
 - 1. Blowdown controller (analog or microprocessor-based)
 - 2. Throttling valve (gate, globe, needle, orifice plates)
 - 3. Blowdown valve (solenoid valve, motorized ball valve)
- B. Installation Guidelines
 - 1. Probe should be located as close to the boiler as possible in a 1" fully ported line (close proximity minimizes the length of time required to heat the probe and obtain an accurate reading).
 - 2. Throttling valve should be located 6"-3' downstream of the probe to prevent steam flashing. Steam flashing will shorten probe life and cause relay chattering.
 - 3. Separate low voltage conductivity wires from other high voltage wires to prevent erratic readings.



Typical Timed-Sampling Installation



possible in a 1" fully ported line with no bends or restrictions. An isolation valve should be installed upstream of the conductivity probe for ease of probe removal and maintenance.

- 2) A flush valve (1/4 turn ball valve) should be installed on the bottom leg of the 1" mounting cross for sediment removal and probe cleaning.
- 3) The throttling valve should be installed between 6" and 3' downstream of the conductivity probe to prevent steam flashing across the probe.
- 4) The blowdown valve should be located far enough downstream of the throttling valve to distance it from high temperature areas. Many blowdown valves feature thermal cutoff switches that can be triggered by high ambient temperatures.



Automated Blowdown Cost Justification

What is the most common "objection" to the purchase of an automatic boiler blowdown system?

Right, it costs too much! Here's a suggestion to help overcome that objection. Analyze the operation and come up with the payback figure.

Take the following example:

A process boiler producing 100,000 pounds per hour of steam: The operator has been told to maintain chlorides at 18-22 ppm. His records show that he averages 20 ppm, which is pretty good for manual blowdown.

However, automatic blowdown could bring the average up to 21 ppm without exceeding 22. This would reduce the blowdown by 5% (21-20) / 20 = .05 or 5%

Typically, 20 ppm results from 10 cycles of concentration. The blowdown required to maintain 10 cycles is $10,000 \, lbs/hr (100,000 / 10 = 10,000)$

If the 10,000 lbs/hr is reduced by 5%, that's a savings of 500 lbs/hr. 500 lbs/hr at 400 BTU/lb is 200,000 BTU/hr. A gallon of oil is about 100,000 BTU, so the oil consumption will reduce by 2 gal/hr. At a dollar a gallon, that's a \$2 savings every hour!

If an automatic blowdown system costs \$1300, it will take 650 hours (or 27 days) to pay for the system!!! (\$1300 / \$2 per hr = 650 hours); (650 hours / 24 = 27 days)

This was all based on zero condensate return. If there is 50% return, the payback period doubles in 54 days. That's still a very short payback period. Of course, the savings continue after the payback period.



Selecting the Right Blowdown Control System

Advantage Controls, Inc. has simplified the selection of our MegaTron, MicroTron and Series-2 analog lines of controllers and valves for automated boiler blowdown. Use the chart at the bottom of the page to select the control system appropriate for your boiler.

To choose the correct system, start with the **blowdown requirement** (in pounds of steam per hour). If unknown, the **blowdown requirement** may be determined from: boiler output or boiler horsepower (**H.P.**); the percentage of return condensate (**% condensate**); and the cycles of concentration (**cycles**).

Use the following formulas to calculate the **blowdown requirement**:

H.P. \times 34.5 = steam output/hr

Steam output/hr x (1-(% condensate/100%)) = make-up water (lbs/hr)

Make-up/hr x (1 / (cycles-1)) = blowdown requirement (lbs/hr)

BLOWDOWN PACKAGE SELECTION GUIDE

Blowdown Required (lbs/hr)	Analog Meter Models	Analog Dial Models	MicroTron Models*	MegaTron Models**	System Pressure (psig)	1/2" Valve Packages*** (Throttling valve & MOBV)
5000 or less	2EZ-B7M	2B-7	LHC	MGB	150 or less 450 or less 1000 or less	AVP-30-10 AVP-40-20 FCH-1/2 & MBWC-1/2
Greater than 5000	2EZ-B8M	2B-8	LHC	MGB	150 or less 450 or less 1000 or less	AVP-30-10-A AVP-40-20-A (2) FCH-1/2 & MBWC-1/2

^{*}MicroTron and MegaTron models are programmable between timed continuous, and sample & hold sampling modes. They are also available with built-in chemical feed timers.

^{**}MegaTron models are available to control up to four boilers with a single controller.

^{***}Valve packages are also available in ¾" – 2" sizes.