

Capacitor Return Motorized Ball Valve with Manual Override

The Capacitor Return Motorized Ball Valve is a ball valve that uses an electric actuator to open or close its mechanism. This type of valve is suited to remote automatic flow control applications such as a cooling tower, industrial water treatment, smart home water treatment system, and many other applications. The motorized ball valve is an economical alternative to a solenoid valve for water treatment professionals looking for a valve that last longer and is more reliable.





FEATURES

- · Long service life
- · Manual override
- · Fast response cut-offs
- · Signal feedback
- · Compact and light weight

APPLICATIONS


- · Cooling Tower
- · Industrial Water Treatment
- · Water Filters & Filtration Systems
- · UF Water Systems
- · Purification Systems
- · Smart Home Water Treatment Systems

ENGINEERING DATA

Size	1/2" FNPT. 3/4" FNPT or 1" FNPT
Connection	NPT
Max Temperature	140°F
Pressure	0-225 PSI
Valve Body, Ball, & Stem	304 SS
Seals	Viton
Voltage	95 - 250 VAC
Torque - Max	2NM
Control	On / Off


Power - Max	5W
Current	25 ± 5mA
Cycle Time	5-7 seconds
Actuator Housing	ABS
Rating	IP67
Cycle Life	70,000+
Junction Box Material	PVC
Power Cord Length	6 foot
Connection Cable	31 1/2 inches

STANDARD WIRING



- $\ensuremath{\mathbb{O}}$ If SW is connected with [OPEN],the valve will open and keep on. O If SW is connected with [CLOSE], the valve will close and keep off.
- NOTE: ★1 SW is double connection plane switch.B2 can take place of bistable solenoid valve.

FEEDBACK WIRING



Instructions:


- $\ensuremath{\mathbb{O}}$ If SW is closed,the valve will open and keep on.
- O If SW is opened,the valve will close and keep off. NOTE:
- ☆1 Same as wiring of monostable solenoid valve. Attention: It should be supplied power at least 10 minutes before cutting the power automatically.

MANUAL OVERRIDE




DIMENSIONS

Without Junction Box



With Junction Box



**PULSAFEEDER*

27101 Airport Road Punta Gorda, FL 33982 Tel: (941) 575-3800 Fax: (941) 575-4085 www.pulsatron.com

